

**308L bottom freezer fridge, white with manual humidity-controlled crisper, Twist & Serve icemaker, easy to clean glass shelves & 3.5-star energy rating**



## Product Details

### FEATURES

---

Full width FreshSeal Crisper with manual humidity control

Twist Ice & Serve Dispenser

Multi-flow air delivery system

Adjustable easy clean glass shelves

---

Flat Door Design

LED lighting

Door alarm

---

### BENEFITS

---

#### FreshSeal Crispers

Our FreshSeal Crisper comes with manual humidity control, so you have greater flexibility to choose the optimum environment to store your fruits and vegetables.

#### Twist Ice & Serve Dispenser

Whether its for an afternoon juice or a whisky on the rocks, our easy access twist ice dispenser and tray allows you to just twist and serve ice simply.

---

#### Glass Shelves

Cleaning your fridge shelves has never been easier. The Westinghouse adjustable glass shelving can be easily manoeuvred allowing you to effortlessly get into every nook and cranny, no matter the mess.

#### Multi-Flow Air Delivery System

Fresher food means tastier food. The Westinghouse Multi-Flow Air Delivery System keeps the temperature stable so every ingredient in the fridge stays fresher for longer.

---

#### Electronic Controls

With the Westinghouse Electronic control system, you can easily change the temperature of your fridge with the touch of a button.

#### LED Lighting

Spend less time with your head in the fridge and more time enjoying your fresh food with Westinghouse LED lighting. More light means you find what you are looking for faster.

---

# Specifications

## PRODUCT PROFILE

Domestic warranty details (yrs)	2
Additional domestic warranty for the sealed refrigeration system only (yrs)	3
Refrigerator Type	bottom mount
Exterior door finish	White
Handle design	integrated
Fridge door opening	reversible (with optional door kit)
Cooling system	frost free
Freezer door opening	right
Refrigerant	R600a

## DIMENSIONS

Total height (mm)	1650
Cabinet height (mm)	1650
Total width (mm)	598
Cabinet width (mm)	595
Total depth (mm)	650
Cabinet depth (mm)	575
Depth door open 90degree (mm)	1199
Air space above cabinet (mm)	50
Food Compartment Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552-2015) *	223
Freezer Compartment Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552-2015) *	85
Total Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552-2015) *	308

## ENERGY

---

Energy Star Rating - 3.5  
AS/NZS 4474.1 2007 (IEC  
62552- 2015) \*

---

Energy Consumption 310  
(kWh/year) - AS/NZS  
4474.1 2007 (IEC 62552-  
2015) \*

---

## FOOD COMPARTMENT

---

### SHELVING

---

Shelf material glass

---

Type of shelf spill safe shelf,adjustable  
shelf

---

## LIGHTING

---

Main light LED

---

## FOOD COMPARTMENT DOOR

---

### BINS

---

Deep bottle bin 1

---

## REFRIGERATOR SYSTEM

---

Controls manual

---

Controls location internal

---

Door alarm fridge

---

## CRISPERS

---

Crisper lid/shelf glass

---

Full width crisper 1

---

Crisper features humidity controlled

---

## OTHER PROPERTIES

---

Other Properties-FOOD  
COMPARTMENT Deodoriser

---

## DAIRY COMPARTMENT

---

Full width dairy, one lid 1

---

1/3 width bins	2
----------------	---

---

## FREEZER COMPARTMENT

---

### ICE FACILITY

---

Twist ice and serve	2
---------------------	---

---

## FREEZER DOOR

---

### INTERNAL

---


Freezer door bins - half width	1
--------------------------------	---

---

Freezer door bins - full width	2
--------------------------------	---

---

# Dimensions



Dimensions	Product Height (H)	Product Width (W)	Product Depth (D)	Product Depth (D2) (Door Open)	Airspace	Side - both	Top	Behind
WBB3100AK	1646	598	650	1199	WBB3100AK	30	90	50
WBB3100WK	1646	598	650	1199	WBB3100WK	30	90	50
WBB3400AK	1756	598	650	1199	WBB3400AK	30	90	50
WBB3400WK	1756	598	650	1199	WBB3400WK	30	90	50

**IMPORTANT**

These dimensions are a guide only. All measurements are in millimetres (mm). For complete installation instructions, refer to the manual provided with product.  
© 2021 Electrolux Home Products Pty Ltd. ABN 51 004 762 341. W\_DIM\_BM\_WBB3100-400\_Oct21

## Terms and Conditions

### IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

### PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

### WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

#### ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: [customercare@electrolux.com.au](mailto:customercare@electrolux.com.au)

web: [www.electrolux.com.au](http://www.electrolux.com.au)

#### ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: [customercare@electrolux.co.nz](mailto:customercare@electrolux.co.nz)

web: [www.electrolux.co.nz](http://www.electrolux.co.nz)