

242L single door fridge, white with 4 tempered glass shelves, 4 full width door bins, fruit & vegetable crisper & a 3 star energy rating. Pair with WFM1700WE for extra storage



Product Details

FEATURES

Reversible door

Auto Defrost

4 x full-width door bins

Egg tray

Fridge light

R600a refrigerant
better for the environment

BENEFITS

Pigeon Pair with WFM1700WE for extra storage solutions
Combining the 243L all refrigerator (WRM2400WE) with our
173L freezer (WFM1700WE) provides you with 416L of storage
for your fresh and frozen goods.

A place for everything
With 4 tempered glass shelves, 4 full-width door bins and a
fruit & veg crisper, we've got plenty of space to store all of
your fresh food and beverages.

Interior LED fridge light
Convenient and efficient, the LED interior light allows you
easier visibility of your food and drink.

Reversible door
The door is reversible so that it may be positioned as either left
or right hand side opening

R600a refrigerant
More environmentally friendly

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Additional domestic warranty for the sealed refrigeration system only (yrs)	3
Refrigerator Type	vertical fridge
Exterior door finish	White
Handle design	integrated
Fridge door opening	reversible
Cooling system	cyclic
Refrigerant	R600a

DIMENSIONS

Total height (mm)	1434
Total width (mm)	550
Cabinet width (mm)	550
Total depth (mm)	545
Depth door open 90degree (mm)	1050
Food Compartment Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552-2015) *	242
Total Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552-2015) *	242
Food compartment capacity (gross in litres)	243
Total Gross Capacity (L)	243
Total Net Capacity (L)	242

ENERGY

REFRIGERATOR SYSTEM

ENERGY

Energy Star Rating - 3
AS/NZS 4474.1 2007 (IEC
62552- 2015) *

Energy Consumption 175
(kWh/year) - AS/NZS
4474.1 2007 (IEC 62552-
2015) *

Energy Star Rating AS/NZS 2.5
4474.2:2009

Energy consumption 241
AS/NZS 4474.2:2009
(kWhr/yr)

FOOD COMPARTMENT

SHELVING

Shelf material glass

LIGHTING

Main light LED

REFRIGERATOR SYSTEM

Controls manual

Controls location internal

Controls type rotary

CRISPERS


Full width crisper 1

OTHER PROPERTIES


Other Properties-FOOD COMPARTMENT Egg tray

Dimensions

WRB5004SC/WC
 WFB4204SC/WC
 WRB3504SA/WA
 WFB2804SA/WA
 WRM2400WE
 WFM1700WE



Minimum Recommended Airspaces



If you have a cupboard above the refrigerator with a rear gap of less than 100mm (Y), recommended minimum clearance at the top of the refrigerator increases from 30mm to 70mm (X).

Please note: Doors are designed to sit proud of cabinetry (not flush).

When positioned in a corner area, clearance of at least 350mm on the hinge side will allow the doors to open enough to enable the removal of the bins and shelves.

Dimensions	Product Height (H)	Product Width (W)	Product Depth (D)	Product Depth (D2) (Door Open)	Airspace	Side - both	Top	Behind
WRB5004SC/ WC	1725	699	641	1360	WRB5004SC/ WC	30	30	50
WFB4204SC/ WC	1725	699	769	1360	WFB4204SC/ WC	30	30	50
WRB3504SA/ WA	1746	595	700	1175	WRB3504SA/ WA	30	30	50
WFB2804SA/ WA	1746	595	700	1175	WFB2804SA/ WA	30	30	50
WRM2400WE	1434	550	545	1050	WRM2400WE	30	30	50
WFM1700WE	1434	550	560	1065	WFM1700WE	30	30	50

IMPORTANT

These dimensions are a guide only. All measurements are in millimetres (mm). For complete installation instructions, refer to the manual provided with product.
 © 2021 Electrolux Home Products Pty Ltd. ABN 51 004 762 341. W_DIM_SD_Oct21

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz