













Fridge Water Filter Guide

Choose the right filter for your fridge using the table below





For pure great tasting water, replace your water filter at least every 6 months

Model Series	Model Image	Compatible Water Filter/s	Visit our Shop
WBE5160		ACC139 / 1450970	Buy Now
WBE5360		ULX220 / 807946705	Buy Now
WHE5160		ACC139 / 1450970	Buy Now

For pure great tasting water, replace your water filter at least every 6 months

Model Series	Model Image	Compatible Water Filter/s	Visit our Shop
WHE5260		ULX220 / 807946705	Buy Now
WHE5264		ULX220 / 807946705	Buy Now
WHE6060		ULX220 / 807946705	Buy Now
WHE6874		ULX220 / 807946705 ACC208	Buy Now Buy Now
WHE7074		ULX220 / 807946705 ACC208	Buy Now Buy Now
WHE7670		ACC140 / 3019986720	Buy Now
WQE6060		ULX220 / 807946705	Buy Now

For pure great tasting water, replace your water filter at least every 6 months

Model Series	Model Image	Compatible Water Filter/s	Visit our Shop
WSE6070		ACC139 / 1450970	Buy Now
WSE6170		ULX220 / 807946705	Buy Now
WSE6870		ULX220 / 807946705	Buy Now
WSE6970		ACC139 / 1450970	Buy Now